

**Eurocode 3 : Design of steel structures – Part 1-1 : General rules and rules for buildings**

**CORRIGENDUM NO. 1**

October 2015

**1. Page 36, 5.3.2 (11)**

Replace equation (5.9)

$$\text{“ } \boxed{AC_2} \ n_{init} = e_0 \frac{N_{cr}}{EI |n_{cr}|_{max}} \ n_{cr} = \frac{e_0}{\lambda} \frac{N_{rk}}{EI |n_{cr}|_{max}} \ n_{cr} \ \boxed{AC_2} \text{ ”}$$

with

$$\text{“ } \boxed{AC_2} \ n_{init} = e_0 \frac{N_{cr}}{EI |n_{cr}|_{max}} \ n_{cr} = \frac{e_0}{\lambda^2} \frac{N_{rk}}{EI |n_{cr}|_{max}} \ n_{cr} \ \boxed{AC_2} \text{ ”}$$